


## Outdoor Updown Wall Light Manual of user

### Summary

- .Base function: Outdoor Updown Wall light
- .Using place : outdoor wall
- .Techinal parameter:

Model no	Voltage	Frequency	Product Size	Power	LUM	CCT	IP
DUVA 9721.12.65.30	AC220-240V	50/60HZ	165*95*55MM	12W	800lm	3000K	65

### Product Image and dimension



### Warning using and installation in according with use of manual

- .The input volatge should no exceed the rate voltage range(Rate voltage: AC220-AC240V 50/60HZ)
- .The Updown wall light can not be installed in the following palce:



**Inclinded place**



**Unfixing Ceiling Board**

- .It is not possible to install the Updown wall light above high temperature object.
- .The Updown wall light is not dimmed and cant not be used with dimmer
- .Inspection and repair , pls entrust a professional to operate.
- .When the Updown wall light fails, pls cut off power quickly and link with manufacture.

### Installation

- .Take out the product from the inner box.
- .Disassemble the light and fix the light base on the wall by 2pcs screw from accessories bag
- .Link the power line in the connector, if connection is wrong, it is easy to casue fire, so firstconnect the GND before connect power line.
- . Fix the light base on the wall by 2pcs screws from accessories bag
- . Install the light cover on the light base by the 2pcs screws.

